


Windmill-Parts.com  
940 597-7735

**REPAIRS  
FOR  
NO. 2  
VANELESS  
MILL**



PART NO.	NAME	10 Ft. No. 2	12 Ft. No. 2	PART NO.	NAME	10 Ft. No. 2	12 Ft. No. 2
4	Crank Plate	\$1.85	\$2.10	E 48	Storm stay for steel Tower	1.50	1.50
5	Wheel spider	4.70	5.85	E 49	Wood tower cap	1.50	1.50
12	Umbrella spider	1.95	1.05	E 50	Crooked end truss rod	.45	.45
13	Upper half of boxing—No. 1	1.05	1.05	E 51	Grasshopper	2.80	2.80
14	Lower half of boxing—No. 1	1.15	1.15	E 52	Double eyed rod	.70	.95
15-1	Clamp for upper guide	.70	.70	E 53	Pull out rod	.60	.60
15	Female half of slide head	.45	.45	E 54	Grasshopper bolt	.30	.30
16	Male half of slide head	.45	.45	E 55	Lower guide for piston	.85	.85
17	Section casting	.70	.70	E 56	Storm stay for wood tower	1.50	1.50
19	Fan rods	.30	.35	E 57	Shifting bar	2.30	2.30
20	Umbrella Rods	.35	.40	E 58	Shifting bar	2.30	2.30
21	Twin rods	.30	.35	E 59	Main shaft	2.70	4.05
E 21	Swivel clamps	.30	.30	E 60	Piston bar	2.90	2.90
E 22	Lower end of swivel	.85	.85	E 61	Upper piston guide	3.85	3.85
E 23	Upper end of swivel	.55	.55	E 62	Wheel spider key	.30	.30
23	Large wood box, 2 pieces	1.25	1.25	E 63	Crank plate key	.25	.25
E 26	Splice irons, 2 pieces	.25	.25	E 64	Large steel tower cap	1.50	1.50
E 27	R & L fan castings	.30	.30	E 65	Contra balance weight	.70	.70
E 30	Governor weight	.45	.95		Bull weight	2.30	2.30
E 31	Set collars	.40	.40		Plate for weight	1.75	1.75
E 32	Arm Castings	.30	.30		Wood arms	.85	.90
E 33	Slide head strap, bottom	.70	.70		Wood section	3.60	3.60
E 34	Slide head strap, top	.60	.60		Wood slat	.12	.12
A 35	Top can for babbitted guide	.45	.45		Wood long section cross bar	.60	.60
E 37	Pump connection	.60	.60		Wood short section cross bar	.45	.45
E 38	Clamp casting	.25	.25		Wood or steel balance weight bar	1.00	1.00
E 40	Upright casting	2.30	2.30		Wood or steel truss upright	.55	.55
E 41	Upright casting clamp	.60	.60		Wood pump rod per 100 ft.	4.40	4.40
E 42	Upright pipe	2.65	2.65		Wood pull out lever	.60	.60
E 43	Piston stud pin	.95	.90		Wood liner for upper guide	.95	.95
E 44	Crank plate wrist pin	.95	.95		Wood liners for Nos. 13 and 14 box	1.15	1.15
E 45	Wood pitman	.85	.85		Cap for upper guide	.45	.60
E 46	Turn table washer	.35	.35		Box bolts	5.30	6.35
E 47	Main frame	4.70	7.06				